Tough Seats 28501 Wilmot Rd Building 1 Unit 10 Trevor, WI 53168 855-579-0538



## **Assembly Instructions Grammer MSG85732**

Includes 1 suspension, one bag of hardware, one seat-top (comes with slides attached) See Figure 1

## How to attach the seat-top to the suspension.

- 1. Start with the seat-top, leave the slide rails on the seat-top
- 2. Place on top of the suspension base. (Figure 2)
- 3. Insert 4 bolts through the slides go into the suspension, can go into front holes or one inch back from front.
- 4. Tighten all 4 bolts using a 1/2" or 13mm wrench.
- 5. Button skirt



Figure 1



Figure 2