

Tough Seats
28501 Wilmot Rd
Building 1 Unit 10
Trevor, WI 53168
855-579-0538



Instructions U2115

This adapter usually comes free of charge and can be used to match most patterns between 8.5-14" wide, can also be used as a spacer as it adds 1.5" of height.

Includes 1 left and 1 right adapter with grade 8 hardware. Typically meant for the long slots to mount to the bottom of the suspension; however these can be flipped in certain situations.

How to attach the suspension

1. Use the slots to align with the bottom of the suspension or the bottom of the slides (if slides are below the suspension) . Slots will move the width narrower or wider. Usually easier to have the gap on the outside in order to tighten nuts.



Figure 1